
Networked PC
26
30
28
18
10
Data Generation Component
LCNA Host Software
User Printer Driver Interface
12
Initialize
Communicate
32
34
o o o
Print Spooler
IP Stack
o o o
20
16
22
Networked LCNA Printer
24
LCNA
Printer Firmware
14

Fig. 1

10025904T10/5590



Fig. 2